



Rehab Solutions Specialists, Inc.

1351 Oakfield Dr., Brandon, FL 33511

Office 813-662-9269

KNEE WORKS 200 HOME USE INSTRUCTIONS

PASSIVE KNEE STRETCHING PROTOCOL



PURPOSE OF THE KNEE WORKS 200

The Knee Works 200 device is designed to help you safely stretch your knee to improve flexibility, restore range of motion, and support your recovery. Follow these instructions carefully for the best results.



1. GENERAL SETUP



Set Up the Device

- Place the Knee Works 200 directly in front of a stable chair with back support.
- Fully extend the stabilizer bars on the base.
- Use the leveling knobs to ensure the device sits flat; check that the bubble is centered on the level indicator.

2. FLEXION (BENDING THE KNEE)



1. Sit comfortably in a chair with your back supported.
2. Place your thigh onto the saddle with your knee 1 to 2 inches above your hip. Make sure there is at least 3 fingers of space between the back of your knee and the start of the saddle. You do not need to secure the strap for Flexion.
3. Use the height adjustment knobs to raise or lower the saddle so your foot does not touch or drag on the floor.
4. Insert the crank handle and turn it to elevate the arm until you can place your foot behind the black roller.
5. Adjust the roller if needed so it sits comfortably at ankle height.
5. Confirm your foot is fully supported and clears the floor.
7. Slowly turn the crank to bend your knee until you feel a strong stretch but **no more than 3 out of 10 pain**.
8. Hold the stretch:
 - Start with 30 seconds.
 - Gradually work up to 1–2 minutes as you tolerate.
9. Repeat 3 to 5 times per day or as instructed by your Clinician.

3. EXTENSION (STRAIGHTENING THE KNEE)



1. Sit comfortably in a chair with your back supported.
2. Place your thigh onto the saddle, and buckle the strap so that the strap falls just behind the knee.
3. Use the height adjustment knobs to raise or lower the saddle so your foot does not touch or drag on the floor.
4. Turn the crank to lower the arm, allowing your ankle to rest in front of the roller.
5. Slowly turn the crank to extend your knee until you feel a strong stretch but **no more than 3 out of 10 pain**.
6. Hold the stretch:
 - Start with 30 seconds.
 - Gradually work up to 1–2 minutes as you tolerate.
7. Repeat 3 to 5 times per day or as instructed by your Clinician.



TROUBLESHOOTING

If the back of the Knee Works unit raises off the ground, increase the height of the knee 1 to 2 inches.



SAFETY GUIDELINES

- Never force the stretch or work through sharp pain.
- Stop immediately if you feel numbness, tingling, unusual discomfort, or swelling.
- Use on a flat, safe surface with no obstructions.
- Discuss any concerns or changes in symptoms with your healthcare provider.



RECOMMENDED FREQUENCY

- Use the Knee Works 200 3–5 times daily for both flexion and extension exercises.
- Follow your therapist or physician's specific recommendations.

PATIENT ACKNOWLEDGEMENT

I acknowledge that I was instructed on the use and function of the Knee Works 200 device and my questions have been answered. If I have any further questions, I know I can call 813-662-9269 for information or reach out to the Rehab Solutions representative listed on the business card provided.

Print Name: _____

Signed: _____

Date: _____

Last Four: _____

Thank you for choosing Rehab Solutions. We are committed to your recovery and well-being.